



Position	Terminal	Concourse	Largest Aircraft	Notes	Passenger Access	Hydrant Fueling	Preconditioned Air	Ground Power	Adjacent Parking Dependencies & Special Operations	Restrictions
M1A	5	M	Saab-340	North side of Delta Air Line Gates	Bussed from Terminal	No (Truck fill only)	No	No	M1B must be vacant to taxi onto M1A	Truck fueling
M1B	5	M	Saab-340	North side of Delta Air Line Gates	Bussed from Terminal	No (Truck fill only)	No	No	M1A must be vacant for M1B to exit	Truck fueling
M14	5	M	B747-400ER	-	Loading Bridge (1)	Yes	Yes	Yes	None	None
M15	5	M	B747-400ER	-	Loading Bridge (1)	Yes	Yes	Yes	None	None
M16	5	M	B747-400ER	-	Loading Bridge (1)	Yes	Yes	Yes	None	None
M17	5	M	B747-8	-	Loading Bridges (2)	Yes	Yes	Yes	M17A must be vacant / No M17A Bridge access to narrow-body	M17A
M17A	5	M	A380-800	-	Loading Bridges (2)	Yes	Yes	Yes	M17 must be vacant	M17A
M18	5	M	B747-400ER	-	Loading Bridge (1)	Yes	Yes	Yes	None	None
M19	5	M	B777-300ER	Closed from May 22 until June 11	Loading Bridge (1)	Yes	Yes	Yes	None	None
M20	5	M	B747-400ER	Closed from June 12 until July 2	Loading Bridge (1)	Yes	Yes	Yes	None	None
M21	5	M	B747-8	-	Loading Bridge (1)	Yes	Yes	Yes	None	None
M24	5	M	B747-400ER	Closed from May 1 until May 21	Loading Bridge (1)	Yes	Yes	Yes	None	None
M25	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M25W must be vacant	M25W
M25W	5	M	B787-10	B777-300ER after May 1	Loading Bridge (1)	Yes	Yes	Yes	M25 and M26 must be vacant	M24/M26
M26	5	M	B737-900	Not open until May 1	Loading Bridge (1)	Yes	Yes	Yes	M25W must be vacant & M27 restricted to narrow-body	M25W/M27
M27	5	M	B777-300ER	Closed from March 26 until May 1	Loading Bridge (1)	Yes	Yes	Yes	M26 must be vacant	M26
M28	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M29W must be vacant	M29W
M29	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M29W must be vacant	M29W
M29W	5	M	A380-800	-	Loading Bridge (2)	Yes	Yes	Yes	Both M28 and M29 must be vacant	M28/M29
M30	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M30W must be vacant	M30W
M30W	5	M	B747-400ER	-	Loading Bridge (2)	Yes	Yes	Yes	Both M30 and M32 must be vacant	M30/M32
M32	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	Both M30W and M33W must be vacant	M30W/M33W
M33	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M33W must be vacant	M33W
M33W	5	M	B747-400ER	-	Loading Bridge (2)	Yes	Yes	Yes	Both M32 and M33 must be vacant	M32/M33
M34	5	M	B747-400ER	-	Loading Bridge (1)	Yes	Yes	Yes	None	None
M35	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M35W must be vacant	M35W
M35W	5	M	B747-400ER	-	Loading Bridge (1)	Yes	Yes	Yes	M35 and M36 must be vacant	M35/M36
M36	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M35W and M37W must be vacant	M35W/M37W
M37	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M37W must be vacant	M37W
M37W	5	M	B747-400ER	-	Loading Bridge (2)	Yes	Yes	Yes	Both M36 and M37 must be vacant	M36/M37
M38	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M39W must be vacant	M39W
M39	5	M	B737-900	-	Loading Bridge (1)	Yes	Yes	Yes	M39W must be vacant and M40 restricted to narrow-body	M39W
M39W	5	M	B747-400ER	-	Loading Bridge (1)	Yes	Yes	Yes	M38 and M39 must be vacant	M38/M39
M40	5	M	A350-1000	-	Loading Bridge (1)	Yes	Yes	Yes	Restricted to narrow-body when M39 is occupied	M39



**Chicago O'Hare  
International Airport**

**Common Use Hardstand Information : March 26, 2023 - October 28, 2023** ★ ★ ★ ★

Position	Terminal	Concourse	Largest Aircraft	Notes	Passenger Access	Hydrant Fueling	Preconditioned Air	Ground Power	Adjacent Parking Dependencies & Special Operations	Restrictions
101	5	Remote	B747-400ER	Hardstand	Stair Truck Only	Yes	No	No	None	None
102	5	Remote	B747-400ER	Hardstand	Stair Truck Only	Yes	No	No	None	None
103	5	Remote	B747-400ER	Hardstand	Stair Truck Only	Yes	No	No	103A must be vacant	103A
103A	5	Remote	A380-800	Hardstand	Stair Truck Only	Yes	No	No	103, 104A and 104 must be vacant	103/104(A)
104	5	Remote	B747-400ER	Hardstand	Stair Truck Only	Yes	No	No	103A, 104A and 104B must be vacant	103A/104(A/B)
104A	5	Remote	B737-900	Hardstand	Stair Truck Only	Yes	No	No	103A and 104 must be vacant	103A/104
104B	5	Remote	B737-900	Hardstand	Stair Truck Only	No (Truck fill only)	No	No	104 must be vacant	None
CD1	Deicing	Remote	B737-900	Central Deicing Position	No	No	No	No	CDW must be vacant (western positions in first, first out)	None
CD2	Deicing	Remote	B737-900	Central Deicing Position	No	No	No	No	CDW must be vacant (western positions in first, first out)	None
CD3	Deicing	Remote	B737-900	Central Deicing Position	No	No	No	No	CDW must be vacant (eastern positions in last, last out)	None
CD4	Deicing	Remote	B737-900	Central Deicing Position	No	No	No	No	CDW must be vacant (eastern positions in last, last out)	None
CDW	Deicing	Remote	B747-400ER	Central Deicing Position	No	No	No	No	All CD1-CD4 must be vacant	None